



# **CRATE STORAGE**




- Keep Stone Top in its crate until installation
- Store crate vertically in a safe location

• Do not stack anything on top of crate

## STONE TOP TRANSPORT




- When moving Stone Top always use a two-person crew.
- Always carry Stone Top vertically.




 Do not carry Stone Top horizontally as it increases the risk of breakage or cracking.



# STONE TOP UNPACKING




• Carefully, without allowing any freefall, rotate the crate from vertical to flat.




• Remove metal bands, unscrew the slats or lid, and lift the Stone Top out of the crate.

# **PARTS LIST**


A. Stone Top



B. Backsplash



C. Basins (x2)



D. Vanity Base



E. Mounting Bracket (x8)



F. Lock Washer (x8)



G Threaded Rod (x8)



H. Wing Nut (x8)





#### STONE TOP INSPECTION

• Before you begin, inspect the Stone Top for cracks and defects. If defects are detected, do not install and please call 800-762-1005. If no defects are detected, clean Stone Top with a soft cloth.

#### **TOOL AND MATERIAL REQUIREMENTS**


- Flat, non-abrasive work surface (blanket or smooth cardboard)
- Sealant
- · Carpenter's level

#### PRIMARY INSTALLATION REQUIREMENTS

- · Professional two-person crew
- · Water supply and drain piping installed according to local plumbing and building codes (sold separately)
- Wall and floor are square and plumb at installation site
- Vanity Base [D] installed square and plumb with wall and floor. Vanity Base [D] also needs to be level
- Ensure Stone Top [A] is the correct size to match the Vanity Base [D]

### **BACK PANEL REMOVAL**


· Remove screws and back panels. Back panels can be discarded or reattached with cutouts to accomodate plumbing.







### **BASIN INSTALLATION**

- 1. Place Stone Top [A] upside down on a blanket or smooth cardboard. Four holes with threaded inserts should be visible for each sink.
- 2. Apply a continuous bead of silicone sealant to the top surface of lavatory Basin [C] rim where it comes in contact with underside of Stone Top [A] (see illustration below).
- 3. Position Basin [C] in its final location. The Basin may need to be repositioned slightly to fit the screws into each hole. Secure Mounting Bracket [E] under the Basin lip. Make sure overflow of Basin is located on the same side as the pre-drilled faucet holes in Stone Top [A].
- 4. Align Threaded Rod [G], Lock Washer [F] and Wing Nut [H] with pre-installed stone top threaded insert and secure on all 4 points with mounting bracket [E].







Sink Bracket Locations



## STONE TOP INSTALLATION



Caution! Installation between two walls requires special care.

If Installing between two walls, stop here and follow the second set of instructions.

#### STANDARD STONE TOP INSTALLATION GUIDELINES

- 1. Using a two-person crew, lift Stone Top and set it on top of the Vanity Base [D].
- 2. Apply Silicone sealant at the seam where Backsplash [B] meets the wall.

### STONE TOP INSTALLATION BETWEEN TWO WALLS


- 1. Using a two-person crew, lift Stone Top and set its rear edge on the back of the Vanity Base [D] (closest to the rear wall). See below illustration.
- 2. Lower front of Stone Top onto the Vanity Base, making sure both ends are lowered at the same rate.
- 3. Do not shimmy, twist or turn the Stone Top while lowering as this increases the risk of breakage.
- 4. Apply Silicone sealant at the seam where Backsplash [B] meets the wall.




## **CLEANING AND MAINTENANCE**


- Avoid abrasive and harsh chemical cleaners.
- RH Stone Tops have a honed finish, hand-polished edges, and are sealed twice with inert silicone sealant.
- Stone Tops should be re-sealed annually.






# VANITY DIMENSIONS IN MILLIMETERS








# **RECTANGULAR STONE TOP**





# **OVAL STONE TOP**








# **RECTANGULAR BASIN**











# **OVAL BASIN**

