



GLASS GLOBE MOBILE PENDANT

ASSEMBLY AND INSTALLATION INSTRUCTIONS

ENGLISH

GLASS GLOBE MOBILE PENDANT**PARTS INCLUDED**



- (A) Ceiling Crossbar (1)
- (B) Canopy 4.7" Ø (1)
- (C) Glass Globe (1)
- (D) Canopy Bolts (2)
- (E) Line Fasteners (3)
- (F) 1.6W LED G4 Bulb (1)

HARDWARE INCLUDED

Pair of Cotton Gloves

TOOLS NEEDED (NOT INCLUDED)

- (G) Wall Anchors (2)
- (H) Screws (2)
- Flat-head Screwdriver
- Power drill
- Pencil



IMPORTANT: PLEASE READ

PLEASE FOLLOW THE ASSEMBLY INSTRUCTIONS CLOSELY. IMPROPER ASSEMBLY OR INSTALLATION CAN RESULT IN PERSONAL OR PROPERTY DAMAGE. MOUNTING HARDWARE HAS BEEN PROVIDED FOR MOUNTING DIRECTLY TO A JUNCTION BOX. UNIQUE OR ALTERNATIVE INSTALLATION TYPES MAY REQUIRE DIFFERENT MOUNTING HARDWARE, WHICH HAS NOT BEEN INCLUDED. ALWAYS CONSULT WITH A LICENSED ELECTRICIAN BEFORE INSTALLATION.

INSTALLATION BY A LICENSED ELECTRICIAN IS STRONGLY RECOMMENDED.

IMPORTANT SAFETY FEATURES**BULBS**

This fixture has been rated for up to 1 (one) 1.6-watt maximum Type G4 LED lightbulb, or up to 1 (one) 5-watt maximum incandescent lightbulb. To avoid the risk of fire, do not exceed the recommended wattage.

VAULTED CEILING COMPATIBILITY

This fixture is vaulted-ceiling compatible, up to a maximum ceiling slope of 45 degrees.

DIMMER SWITCH COMPATIBILITY

This fixture is dimmer-switch compatible, and may only be used with an ELV/trailing-edge dimmer switch.

WARNINGS

All wires are connected. When unpacking, be careful not to pull wires, as damage may result. Do not connect electricity until the fixture is fully assembled. To reduce the risk of fire, electrical shock, or personal injury, always turn off the fixture and allow it to cool prior to replacing the lightbulb. Do not touch or look directly at the bulb when the fixture is illuminated. Keep flammable materials away from lit bulb.

WARNING: STRANGULATION HAZARD




Keep cord at least 3 feet away from cribs, bassinets, and toddler beds. Keep out of reach of children under 3 years of age.



THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.


SAFETY PRECAUTION WHILE INSTALLING AND USING LIGHTING FIXTURE:

The manufacturer (reseller) shall not be held liable for any damage caused by improper installation and operation. The installation and wiring connection must be performed by a licensed professional. All applicable regulations and norms shall be observed while installing the fixture. Make sure you cut off electrical supply at the main fuse box/circuit breaker before commencing any work.

This fixture is for indoor use only. 

Avoid mounting on wet surfaces or surfaces with high conductivity. Wires to be connected with push-in wire connectors in line with EN 60998. The connector terminal should hold safety certificates applicable in Poland and the European Union. A fixture of Class I protection  should be connected to electrical ground  with an earth conductor (green and yellow wire). A fixture of Class II protection  includes double-insulation wiring and cannot be connected to electrical ground. Make sure the wiring is not damaged during installation. Should the fixture be damaged, it should be replaced with the same type, voltage, and wattage (see label). Protect the fixture against any water or humidity contact with power supply. If the fixture is to be mounted in rooms with bathtubs/showers, electrical installation regulations for buildings shall apply.

The fixture uses irreplaceable Z-Type wires. No replacement of internal or external wiring shall be performed by users. It will always lead to irreversible modifications of intended fixture parameters and may lead to improper operation and risk to the user.  Class II protection (with safety insulation) – electrical ground (yellow and green wire) must not be connected.  Class I protection – light fixture must be connected to electrical ground wire with an earth conductor (green and yellow wire). Fixtures to be used indoor in temperatures at about 25°C.

Do not touch 

Risk of burning 

Broken glass must be replaced   

ENVIRONMENT PROTECTION NOTE:

Used electrical appliances are recyclable – they cannot be disposed of with regular waste as they may contain substances that are hazardous to human health and the environment. Pursuant to the WEEE directive (Directive 2012/19/EU) applicable in the European Union, electrical and electronic equipment must be collected and treated separately.



Any user intending to dispose of this product shall be obliged to take it to the collection point for electrical and electronic equipment, such as the distributor of the equipment or any other unit providing such services.

The manufacturer (reseller) shall not be held liable for any damage or harm caused by improper operation of the fixture.

SAFETY INSTRUCTIONS:

These instructions are provided for your safety. It is very important that they are read completely before beginning the installation of the fixture.

1. Turn off electricity at the main circuit breaker panel before beginning installation.
2. This direct wire fixture must be installed by a certified and licensed electrician. Customers should not attempt to install it on their own.
3. This fixture has been rated for up to 1 (one) 1.6-watt maximum Type G4 LED lightbulb, or up to 1 (one) 5-watt maximum incandescent lightbulb. To avoid the risk of fire, do not exceed the recommended wattage.
4. If any special control devices are used with this fixture, follow the instructions to assure full compliance with the N.E.C. requirements.
5. This fixture can be used only with an ELV/trailing-edge dimmer.
6. The mounting hook with wall anchor is not included. To select the proper type of mounting hook/wall anchor based on the material the ceiling is made of, please contact your local hardware store for assistance. If there are any questions, contact a licensed electrical contractor.

WARNINGS

- Do not mount or unmount the glass globe if the lightbulb or fixture is hot.
- All wires are connected. Do not remove the ceiling light from its packaging by pulling on the power cord, as a bad connection may result.
- Do not use if the light cable/cord is damaged.
- To reduce the risk of fire, electrical shock, or personal injury, always turn off the light fixture and allow it and the globe to cool prior to replacing the lightbulb.
- When mounting the fixture, always use the included white gloves.
- Do not touch the bulb when the fixture is turned on. Do not look directly at lit bulb.
- Keep flammable materials away from lit bulb.

FCC COMPLIANCE:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


IC COMPLIANCE:

This Class B digital apparatus complies with
CAN ICES-005 (B) /NMB-005(B).


RESTORATION HARDWARE
15 KOCH ROAD
CORTE MADERA, CA 94925
1-800-762-1005

ASSEMBLY AND INSTALLATION**SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE FUSE BOX OR CIRCUIT BREAKER PANEL.**


1. After removing the fixture frame from the box, use a Flat-head Screwdriver (not included) to unscrew Canopy Bolts (D) attached to Ceiling Crossbar (A).




2. The fixture can be used on vaulted ceilings with a maximum of 45 degrees. NOTE: Pay special attention to the recommended positioning of Ceiling Crossbar (A) against the sloping ceiling, as shown in the diagram.




3. Place Ceiling Crossbar (A) flush against the ceiling, near the electrical cords hanging from the ceiling. Mark 2 spots for Wall Anchors (G) (not included). Drill holes in the spots you marked, and insert Wall Anchors (G). NOTE: Consult your local hardware store for proper Wall Anchors (G).




4. Insert Screws (H) (not included) to secure Ceiling Crossbar (A) onto the ceiling.




5. Are you adjusting the fixture line length?
YES: Continue to Step 6.
NO: Jump to Step 7.




6. Loosen the bolt in Line Fasteners (E), and carefully pull or push the line to the desired length. Screw the bolt in, up to 1.5Nm, to secure it in position. Any excess lines should be coiled into Canopy (B).




7. Lift the fixture up and hold it under Ceiling Crossbar (A) to make electrical connections. NOTE: It is recommended that 2 (two) people assist for this step, and the the following 2 steps.



8. Junction boxes may vary depending on location. The diagram on the right shows the most common markings and manner of connecting the cords. **NOTE:** We recommend installation by a licensed electrician.




9. Lift Canopy (B) up and hold it against Ceiling Crossbar (A), so that the openings in Canopy (B) match the openings in Ceiling Crossbar (A). Use Canopy Bolts (D) to secure Canopy (B) to Ceiling Crossbar (A).




10. Carefully insert the included 1.6W LED G4 Bulb (F) into the slot at the tip of the fixture line.



11. Start mounting Glass Globe (C) first by removing the plastic stopper. **NOTE:** Included Cotton Gloves must be worn when handling Glass Globe (C).



12. Slide Glass Globe (C) onto the bulb tip and screw it on by first gently turning it counterclockwise until you hear a click, and then turn it clockwise. Ensure Glass Globe (C) turns straight onto the thread.



13. Restore power to the fixture. Assembly is complete.



CLEANING AND MAINTENANCE

NOTE: ENSURE TO CUT OFF ELECTRICAL SUPPLY TO THE FIXTURE BEFORE COMMENCING CLEANING OPERATIONS.

BRASS FRAME: Clean every month using a soft cloth, dampened slightly with water. Make sure the frame is dry before switching it back on. Tools: Soft cloth, water.

GLASS GLOBES: Clean regularly with a soft, dry cloth. Clean only the outside of the globe. When dirtier, use a wet cloth first. Grease can be cleaned with a gentle glass cleaner. Tools: Soft cloth, cotton gloves.

LED BULBS: Make sure your power supply is off before changing the bulb. Unscrew the globe where the bulb needs replacing. Gently remove the bulb by pulling it out and replace with an LED bulb of the same parameters. Tools: Cotton gloves, LED bulbs.

NOTE: PLEASE REMEMBER SOLID BRASS MAY TARNISH OVER TIME. THIS IS A NATURAL PROCESS. ENSURE TO FOLLOW THE GUIDELINES TO PRESERVE THE LOOK OF THE FIXTURE FINISH.

TROUBLESHOOTING

NOTE: THE HANDMADE NATURE OF THE PRODUCT OFFERS A UNIQUE AESTHETIC EXPERIENCE AND ALLOWS FOR SMALL IMPERFECTIONS, WHICH IS INHERENT IN CRAFTS. IF SOLUTIONS OFFERED BELOW ARE NOT SUFFICIENT, PLEASE DO NOT HESITATE AND CONTACT RH CUSTOMER SERVICE.

PROBLEM: TARNISHING

Oxidation of brass is a natural process. Although it is lacquered, its color may change slightly over time. No action is necessary apart from regular cleaning. See the CLEANING AND MAINTENANCE section above.

PROBLEM: NOISE

The humming noise normally comes from transformers. Check electrical connections and make sure the right dimmer is used – ELV.

PROBLEM: GLOBE DEFORMATIONS

Mouth-formed glass globes are unique and imperfect. The process leaves a slight deformation at the bottom of the globe. No action is necessary. All globes undergo a quality check. Should you have any concerns, please contact RH customer service.