

RESTORATION HARDWARE

KLEIN TABLE LAMP

PARTS ENCLOSED

- (A) Finial
- (B) Shade (sold separately)
- (C) Riser
- (D) Plug Cover
- (E) CFL Bulb

IMPORTANT SAFETY INSTRUCTIONS

WE RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.

This fixture has been rated for up to (2) 60-WATT MAX. TYPE A BULBS or self-ballasted CFL bulb13W (included). To avoid the risk of fire, do not exceed the recommended wattage.

WARNINGS

1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
2. To reduce the risk of fire, electrical shock, or personal injury, always turn off lamp and allow it to cool prior to replacing light bulb.
3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
4. Keep flammable materials away from lit bulb.
5. This lighting fixture contains lead, a chemical known to the State of California to cause cancer, birth defects and other reproductive harm. Wash hands after installing, handling, cleaning or otherwise touching this light fixture.
6. Remove all parts and hardware from box along with any plastic protective packaging.
7. Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

TO ASSEMBLE

SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER!

1. Carefully remove all parts from the box and remove all plastic covering.
2. Screw adjustable Riser (C) to the top of lamp body.
3. Remove finial (A) from the adjustable Riser (C).
4. Place Shade (B) (not included) to the assembled adjustable Riser (C) and secure with Finial (A).
5. Insert Bulbs (2) 60-WATT MAX. TYPE A BULBS or self-ballasted CFL bulb13W (included) into the sockets.
6. Remove protective Plug Cover (D) from the plug.
7. Plug into a proper electrical outlet and test the fixture.
8. Assembly is complete.

CARE INSTRUCTIONS

Wipe all surfaces with a soft dry cloth. Do not use any harsh cleaners (including ammonia-based products) or abrasives, as they will damage the finish.

