

RH

THADDEUS FLOOR MIRROR 42" (107CM) X 78" (198CM)

ASSEMBLY AND INSTALLATION INSTRUCTIONS

ENGLISH

THADDEUS FLOOR MIRROR 42" (107CM) X 78" (198CM)

PART LIST


- 1. Mirror

HARDWARE LIST

- (A) Hangman Wall Bracket 32" (81cm) (1)
- (B) Hangman Wall Bracket 24" (61cm) (1)
- (C) Screw (14)
- (D) Bracket (4)
- (E) Clevis pin (4)
- (F) Hitch pin (4)
- (G) Galvanized steel cable (2)
- (H) 5/8" Screw (16mm) (4)
- (I) 1-1/2" Screw (38mm) (4)
- (J) Hollow Wall Anchor (4)

TOOL AND MATERIALS REQUIRED

- (1) Screwdriver
- (2) Pencil
- (3) 3/8 Drill Bit (for wall anchor)
- (4) Hand Drill
- (5) Carpenter Level



BEFORE YOU BEGIN

1. Be sure to check all packaging materials carefully for small parts that may have become loose during shipment and place all parts on a non-abrasive surface.
2. Professional installation recommended.

STORAGE

1. Do not stack anything on top of the mirror.
2. Keep the mirror packaged until installation.
3. Store mirror upright on the long edge.


MIRROR HANDLING INSTRUCTIONS**CAUTION**

1. Remove vertically from package
2. Always carry mirror vertically as illustrated. Carrying flat will cause breakage.

SAFETY INSTRUCTIONS

1. Professional installation is strongly recommended.
2. For your safety, it is recommended that two people hang the fixture.
3. These instructions are provided for your safety. They must be read carefully and completely before the installation of the fixture.
4. Check with a professional installer to ensure your wall can tolerate a fixture with two times the weight of the mirror.

NOTE: For safe mounting, it is important to use the proper hardware for your wall type. The included hardware is for stud mounting only. If the mounting bracket cannot be secured to a wall stud because of inappropriate spacing and/or because you have a different wall type (e.g., plaster, concrete, brick, etc.) please consult your local hardware store for fastener advice.




WARNING


1. These mirror parts can be cumbersome to some people, therefore the assistance of two or more people is recommended to prevent personal injury and ensure the mirror is not damaged during the assembly process.
2. Serious injury or death can occur if the mirror is not hung correctly. Do not use wire to hang. Please follow the correct hanging methods for the wall type. Consult a professional before hanging.

HERE ARE SOME GUIDELINES AS FOLLOW


1. If the wall is CONCRETE/MASONRY, drill a hole on each mark and then insert a plastic wall anchor on each hole. Use a screwdriver to attach the bracket to the wall.
2. If the mirror wall bracket will be installed on DRYWALL ALONG WITH THE STUDS use a screw to fasten the wall bracket.
3. If the mirror wall bracket will be installed only on the DRYWALL, use hollow wall anchors to fasten the bracket.



CONCRETE/MASONRY



DRY WALL WITH STUDS
Screw inserted directly into stud



DRYWALL WITHOUT AVAILABLE
WOOD STUD
Plug with wall anchor

ASSEMBLY INSTRUCTIONS

1. According to your preference, you can conveniently install this mirror in a landscape or portrait position. Pre-set the mirror on your desired location and mark the location with a light pencil mark. Use tape or pencil to transcribe the location of the wall into the mirror bracket.
2. Hold the bracket against the wall and check the alignment of both ends of the bracket that has the same distance on the floor or ceiling surface.
3. After checking the level, fasten the brackets against the wall with screws provided in your hardware packed. Please see FIGURE 01.
4. Install the mirror on the wall bracket as illustrated in FIGURE 02.

FIGURE 01





FIGURE 02



NOTE: This Mirror is Designed to lean against a wall or may be mounted to the wall with included hanging hardware. If using as a leaner mirror, we encourage the installation of the included tip-restraint, which securely anchors the product to the wall. Items not properly anchored pose a potential safety risk. Professional installation is recommended for mirrors weighing more than 100 lbs. (45,4kg), and when mounting on a tile or stone surface.

5. On the back surface of the mirror are two pins pre-installed and cavities for the hitch pin to pass through. Install one end of the galvanized steel cable on the pre-installed pin and secure this with a hitch pin as shown in FIGURE 03.
6. Pre-set the mirror against the wall at eight degrees (8°) angle. Mark the locations on the wall approximately 1" (25mm) below to the wall side brackets along the selected studs mark, or opposite to the back of the mirror clevis pin.

NOTE: If wood studs are not available, please refer to the separate instruction on the anti-tip kit pack for hollow walls.

7. Secure the brackets to the wall with screws provided in the hardware pack. Please see FIGURE 04.
8. Align the pre-installed clevis pin at the back of the mirror with the brackets in the wall.
9. Attach the Galvanized Steel Cable to the bracket and secure it with a clevis pin and hitch pin. Please see FIGURE 05.

FIGURE 03




FIGURE 04






FIGURE 05



WARRANTY

If you are not completely satisfied with your purchase, please contact us to return or exchange your item(s) within 30 days of the delivery date, with proof of purchase. Note that returns or exchanges are not accepted for special orders, items that have been installed, mattresses and/or foundations no longer in their original packaging, and other items listed below. Other exclusions may apply. Contact us for details. Unfortunately, galleries cannot accept returns of furniture or other large items.

CLEANING INSTRUCTIONS

To maintain and protect the luster of all product clean with a soft damp cloth only.

RH

THADDEUS FLOOR MIRROR 24" (61CM) X 80" (203CM)

ASSEMBLY AND INSTALLATION INSTRUCTIONS

ENGLISH

THADDEUS FLOOR MIRROR 24" (61CM) X 80" (203CM)

PART LIST


- 1. Mirror

HARDWARE LIST

- (A) Hangman Wall Bracket 48" (122cm) (1)
- (B) Hangman Wall Bracket 18" (46cm) (1)
- (C) Screw (12)
- (D) Bracket (4)
- (E) Clevis pin (4)
- (F) Hitch pin (4)
- (G) Galvanized steel cable (2)
- (H) 5/8" Screw (16mm) (4)
- (I) 1-1/2" Screw (38mm) (4)
- (J) Hollow Wall Anchor (4)

TOOL AND MATERIALS REQUIRED

- (1) Screwdriver
- (2) Pencil
- (3) 3/8 Drill Bit (for wall anchor)
- (4) Hand Drill
- (5) Carpenter Level



BEFORE YOU BEGIN

1. Be sure to check all packaging materials carefully for small parts that may have become loose during shipment and place all parts on a non-abrasive surface.
2. Professional installation recommended.

STORAGE

1. Do not stack anything on top of the mirror.
2. Keep the mirror packaged until installation.
3. Store mirror upright on the long edge.

MIRROR HANDLING INSTRUCTIONS


CAUTION

1. Remove vertically from package
2. Always carry mirror vertically as illustrated. Carrying flat will cause breakage.

SAFETY INSTRUCTIONS

1. Professional installation is strongly recommended.
2. For your safety, it is recommended that two people hang the fixture.
3. These instructions are provided for your safety. They must be read carefully and completely before the installation of the fixture.
4. Check with a professional installer to ensure your wall can tolerate a fixture with two times the weight of the mirror.

NOTE: For safe mounting, it is important to use the proper hardware for your wall type. The included hardware is for stud mounting only. If the mounting bracket cannot be secured to a wall stud because of inappropriate spacing and/or because you have a different wall type (e.g., plaster, concrete, brick, etc.) please consult your local hardware store for fastener advice.




WARNING


1. These mirror parts can be cumbersome to some people, therefore the assistance of two or more people is recommended to prevent personal injury and ensure the mirror is not damaged during the assembly process.
2. Serious injury or death can occur if the mirror is not hung correctly. Do not use wire to hang. Please follow the correct hanging methods for the wall type. Consult a professional before hanging.

HERE ARE SOME GUIDELINES AS FOLLOW


1. If the wall is CONCRETE/MASONRY, drill a hole on each mark and then insert a plastic wall anchor on each hole. Use a screwdriver to attach the bracket to the wall.
2. If the mirror wall bracket will be installed on DRYWALL ALONG WITH THE STUDS use a screw to fasten the wall bracket.
3. If the mirror wall bracket will be installed only on the DRYWALL, use hollow wall anchors to fasten the bracket.



CONCRETE/MASONRY



DRY WALL WITH STUDS
Screw inserted directly into stud



DRYWALL WITHOUT AVAILABLE
WOOD STUD
Plug with wall anchor

ASSEMBLY INSTRUCTIONS

1. According to your preference, you can conveniently install this mirror in a landscape or portrait position. Pre-set the mirror on your desired location and mark the location with a light pencil mark. Use tape or pencil to transcribe the location of the wall into the mirror bracket.
2. Hold the bracket against the wall and check the alignment of both ends of the bracket that has the same distance on the floor or ceiling surface.
3. After checking the level, fasten the brackets against the wall with screws provided in your hardware packed. Please see FIGURE 01.
4. Install the mirror on the wall bracket as illustrated in FIGURE 02.

FIGURE 01





FIGURE 02



NOTE: This Mirror is Designed to lean against a wall or may be mounted to the wall with included hanging hardware. If using as a leaner mirror, we encourage the installation of the included tip-restraint, which securely anchors the product to the wall. Items not properly anchored pose a potential safety risk. Professional installation is recommended for mirrors weighing more than 100 lbs. (45,4kg), and when mounting on a tile or stone surface.

5. On the back surface of the mirror are two pins pre-installed and cavities for the hitch pin to pass through. Install one end of the galvanized steel cable on the pre-installed pin and secure this with a hitch pin as shown in FIGURE 03.
6. Pre-set the mirror against the wall at eight degrees (8°) angle. Mark the locations on the wall approximately 1" (25mm) below to the wall side brackets along the selected studs mark, or opposite to the back of the mirror clevis pin.

NOTE: If wood studs are not available, please refer to the separate instruction on the anti-tip kit pack for hollow walls.

7. Secure the brackets to the wall with screws provided in the hardware pack. Please see FIGURE 04.
8. Align the pre-installed clevis pin at the back of the mirror with the brackets in the wall.
9. Attach the Galvanized Steel Cable to the bracket and secure it with a clevis pin and hitch pin. Please see FIGURE 05.

FIGURE 03




FIGURE 04






FIGURE 05



WARRANTY

If you are not completely satisfied with your purchase, please contact us to return or exchange your item(s) within 30 days of the delivery date, with proof of purchase. Note that returns or exchanges are not accepted for special orders, items that have been installed, mattresses and/or foundations no longer in their original packaging, and other items listed below. Other exclusions may apply. Contact us for details. Unfortunately, galleries cannot accept returns of furniture or other large items.

CLEANING INSTRUCTIONS

To maintain and protect the luster of all product clean with a soft damp cloth only.